

PTU50-51-56

Ultrasonic level transmitter

825B124C

Technical Data

Housing material:	PP
Mechanical installation:	1" GAS M; (PP flange DN100 opt.)
Protection degree:	IP68
Electrical connection:	IP68 male connector with 5/10/15/20m linking cable
Working temperature:	-25° ÷ +75°C
Pressure:	da 0,5 a 1,5 bar (absolute)
Power supply:	24Vdc
Power consumption:	1,5W
Analog output:	4÷20mA max 750ohm
Digital communication:	MODBUS RTU
Max measure range:	PTU50 0.05÷1.5m; PTU51 0.3÷6m; PTU56 0.5÷12m
[In case of non perfectly reflecting surfaces, the maximum distance value will be reduced]	
Temperature compensation:	digital in the working temperature
Accuracy:	±0,2% (of the measured distance) not better than ±3mm (PTU50 ±1mm)
Resolution:	1mm
Calibration:	VLW601 prog. module with 4 buttons or by MODBUS RTU
Warm-up:	30 minutes typical
LCD Display:	matrix LCD display on VLW601 module (opt.)



Warranty

Products supplied by SGM LEKTRA are guaranteed for a period of 12 (twelve) months from delivery date according to the conditions specified in our sale conditions document.

SGM LEKTRA can choose to repair or replace the Product.

If the Product is repaired it will maintain the original term of guarantee, whereas if the Product is replaced it will have 12 (twelve) months of guarantee.

The warranty will be null if the Client modifies, repair or uses the Products for other purposes than the normal conditions foreseen by instructions or Contract.

In no circumstances shall SGM LEKTRA be liable for direct, indirect or consequential or other loss or damage whether caused by negligence on the part of the company or its employees or otherwise howsoever arising out of defective goods

Factory Test Certificate

In conformity to the company and check procedures I certify that the equipment:

PTU..... Production and check date:

Serial n.

is conform to the technical requirements on Technical Data and it is made in conformity to the SGM-LEKTRA procedure

Quality Control Manager



Process Control and Measurement

The non intrusive system application is now preferred in the level measurements field. For this reason the **SGM-LEKTRA** developed the **PTU50**, **PTU51** and **PTU56** unity to best meet the “**GENERAL-PURPOSE**” application requests. The **PTU50**, **PTU51** and **PTU56** units are compact sensors and have a via connector quick connection. The **IP68** protection makes them suitable for external applications with direct exposure to the weather, including areas with diving hazard (up to 1m). **PTU50**, **PTU51** and **PTU56** are ultrasonic level transmitter, temperature-compensated and suitable for connection with **MODBUS RTU**.

- ☐ **Non-contact level measurements**
- ☐ **Suitable for liquids and granulates level measurement**
- ☐ **Integrated digital temperature sensor to compensate the measure**
- ☐ **MODBUS RTU communication protocol**
- ☐ **24Vdc power supply**
- ☐ **Mechanical protection: IP68**
- ☐ **1 4÷20mA analog output**

1. SAFETY

1.1 Installation precaution

- a) Installation shall only be performed by qualified personnel and in accordance with local governing regulations.
- b) Make sure that the working temperature is between -35° and +75°C
- c) Install the transmitter in a its physical characteristics and housing/sensor construction materials compatible environment.
- d) The transmitter must be used safety warnings observance.
- e) Improper transmitter use would cause serious damage to people, to the product and connected equipment.


2. INSTALLATION

2.1 Mechanical dimensions





The **PTU50**, **PTU51** and **PTU56** transmitter have the 1" GAS M threaded, equipped with 1" PP fixing bolt.
Also available with:

PTU50-51 - DN100 PN6 UNI 1092-1/PP flange (optional accessory)

PTU56 - DN120 PN6 UNI 1092-1/PP flange (optional accessory)





2.2 Mounting examples



2.3 Mounting precautions

2.3.1 Mounting position (Fig.8)

- With cambered roof, Do not install the sensor in the tank center (b). Leave a 300mm minimum distance between the sensor and the tank smooth wall (d).
- Use a protective cover to protect the sensor from weather and direct sunlight (c).
- Do not install the sensor near the load zone (a).
- Make sure that in the sensor emission beam (lobe " α ") there are no obstacles (f,s) that can be intercepted as level.
- Make sure that there is not foam presence on the product surface to be measured



	Lobe α	L	d
PTU50 6m	10°	1.5m	0.02m (1.5m)
PTU51 6m	10°	6m	0.6m (6m)
PTU56 12m	10°	12m	1m (12m)

2.3.1 Blind distance

During installation is important to remember that in the sensor vicinity there is a blind zone (or **BLIND DISTANCE**) of **0.05m** (for 1.5m max **PTU50** range), **0.3m** (for 6m max **PTU51** range) or **0.5m** (for 12m max **PTU56** range) where the sensor can not measure.

Tab.1





Fig.9

2.3.2 Installation in nozzle

Installing the **PTU50-51-56** sensor in a nozzle (see fig.10), make sure the sensor bottom protrudes at least 10 mm from the bottom nozzle



PTU50-51-56 can be installed in an extension pipe (see Figure 11) to turn away the sensor from the maximum level point. The extension pipe must be flat and without joints (welds, etc.), also, the pipe terminal part must be cut at 45° and with the borders without burr.

PTU50 1.5m - PTU51 6m		PTU56 12m	
D (mm)	Lmax(mm)	D (mm)	Lmax(mm)
100	80m	125	240
125	240	150	300
150	300		

Tab.2




Fig.11

2.3.4 Reference pipe installation

Disturbing factors that may influence the level measurement in liquids, as for example:

- foam presence on the product surface (Fig.12)
- internal structures presence in the tank (Fig.13)
- presence on the liquid surface of floating bodies (Fig.14)

can be avoided with the use of level measurement inside of pipes (by-pass pipe or calm pipe with 100mm min. diameter for PTU50-51, or 125mm min. diameter for PTU56)

The pipe must have a length greater or equal than the empty distance, also, must have some of vent holes (Fig. 14-A) to allow the pipe regular filling and emptying.

In the programming menu, to the **"PRODUCT"** parameter, must select the **"LIQUID PIPE"** option (see page 7 or 11)

Fig.12




Fig.13




Fig.14





Fig.14-A



2.3.5 Agitators presence

The level measurement is possible thanks to the **Auto-Tuned** statistical filter. Should rarely need to adjust the filter setting by editing 2 **PTU50-51-56** sensor programming parameters:

- **FILTER**; this parameter is present in the **Quick Setup** menu (page 8) and in the Advanced Configuration **"SETUP"** menu (page 11); increasing the parameter value, decreases the sensor sensitivity to the level measurement sudden variations.
- **F-WINDOW**; this parameter is present in the Advanced Configuration **"SERVICE"** menu (page 18); decreasing the parameter programmed value, increases the sensor immunity to false echoes.



Fig.15

2.3.6 Mechanical installation accessories




Fig.16

3. CONNECTIONS

3.1 Wiring

- 1) Separate the engine control cables or power cables from the **PTU5x** connection cables.
- 2) Isolate unused wires of the cable.
- 3) Fully tighten the connector ring nut

Brown	GND (0V)	Green	A (RS485)
Red	+24Vdc	Blue	B (RS485)
White	SDA Display	Pink	+3.3V Display
Yellow	+ 4÷20mA	Grey	SCL Display

The immunity to electromagnetic interference complies with **CE** Directives

3.2 Humidity infiltrations

To avoid the humidity infiltration inside the connector is recommended:

- Fully tighten the connector ring nut
- position the cable so that it forms a downward curve at the M20 output (Fig. 18); in this way the condensation and/or rain water will tend to drip from the curve bottom




Fig.17




Fig.18

4. CONFIGURATION MODES

The **PTU50**, **PTU51** and **PTU56** have 2 configuration/calibration modes:

- via **MODBUS RTU**, by PC
- via **VLW601** programming module

4.1 Via MODBUS RTU

4.1.1 MODBUS RTU PC connection (fig.19)

- 1) **PTU50**, **PTU51** or **PTU56** with **MODBUS RTU** communication protocol
 - 2) USB/RS485 interface module, cod.694A004A
 - 3) **MODBUS RTU** communication S/W, cod.010F105A (3)
- With this software is possible:
- connect, by selecting the **UID** address, the **PTU50**, **PTU51** or **PTU56** transmitters in **MODBUS RTU** network
 - read on your PC monitor all measures in reading and **PTU50**, **PTU51** or **PTU56** operation data
 - programming all **PTU50**, **PTU51** or **PTU56** configuration parameters
 - storing on files, data logger function; **PTU50**, **PTU51** or **PTU56** measures in reading and operating states




Fig.19

4.3 via VLW601 configuration

With the **VLW601** display module (Fig. 20) is possible to display the measured values and configure the **PTU50**, **PTU51** and **PTU56** sensors operating parameters. The **VLW601** module is equipped with matrix LCD.



displayed at the bottom indicates the correct echo signal reception



displayed at the top alerts that there is a generic error; press to show the message that indicates the present error type.
The **PTU50**, **PTU51-56** returns automatically to RUN mode.













Fig.20

PTU5x - Configuration and Quick Start

The **VLW601** program module has 4 buttons (fig. 21) which allow to perform all operational, control and programming instrument functions.

In the configuration menus, is possible:

- Submenus and parameters access; press  to select and press  to access.
- Parameter options choice: Press  to select the option and press  to store the option.
Press  to exit without storing
- Configure the parameter values; in some parameters the configuration is done by setting a value (eg., in the **SET DISTANCE 4mA** parameter is possible to change the the corresponding distance value, in mm): press  to select the digit to be modified (the digit is highlighted in **inverse**), press  to change the highlighted digits number, press  to save the set value and exit automatically. Press  to exit without storing.

In the display top right, during the settings, there is always a number, eg. "1.2". This number is the menu or parameter index that's displayed. The menu structure is represented on page 7 and on pages 9÷10.

















Fig.21


-  - Configuration access
-  - Options confirmation
-  - Parameters values confirmation
-  - Parameters values selection
-  - Parameters scroll
-  - Parameters values modification
-  - Exit configuration
-  - Back to previous menu


With the VLW601 module is possible to access two configuration modes for the PTU50-51-56 setting:




- ☐ **QUICK START** - Menu with easy access for quick basic parameters configuration.
To access: from "RUN" mode press  to the quick setup menu mode access,  to exit
- ☐ **ADVANCED CONFIGURATION** - Full menu with access to all parameters, including functional parameters.
It is recommended to carefully read the complete documentation before accessing.
To access: from "RUN" mode, holding down  , press  to the advanced configuration mode access,  to exit



WARNING! - The documentation provided with the **PTU50-51-56** contain the most frequently used indications. If it's necessary refer to the full manual, it can be downloaded from our website www.sgm-lektra.com , in the products section.

5. QUICK START MODE


From "RUN" mode press  to access the Quick Setup menu



Select the parameters by moving the cursor with , and confirm with ; press  to exit





5.1 Struttura menù di configurazione rapida



5.1.1 SET DISTANCE 4mA

Press **OK** to display the distance value associated with 4mA output.

Use **↓** and **↑** to modify that value; in the Fig.22 example, the 4mA distance is 3500mm. Press **OK** to confirm.



5.1.2 SET DISTANCE 20mA

Press **OK** to display the distance value associated with 20mA output.

Use **↓** and **↑** to modify that value; in the Fig.22 example, the 20mA distance is 500mm. Press **OK** to confirm.






Fig.22

5.1.3 MEDIUM

Press **OK** to display the previous setting

Press **↓** to select the medium type. Press **OK** to confirm.

In fig.23 product selection example.






Fig.23

5.1.4 FILTER COEFFICIENT

Press **OK**. Increasing the value slows down the sensor response speed.

Use **←** and **→** to modify the value. Input a value from 1 to 99. Press **OK** to confirm.

In fig.24 value choice example.





Fig.24



5.1.5 BLIND DISTANCE

Press **OK**. The **BLIND ZONE** is used to avoid undesired measures near to the transmitter

Use **←** and **→** to modify the value. Press **OK** to

confirm. The minimum value is 50mm (PTU50), or 300mm (PTU51) or 500mm (PTU56).







Fig.25

5.1.8 DISPLAY

Press **OK** to access the settings change.



With the **←** button is possible to select the data to display
Press **OK** to confirm.

5.2 ECHO MAP

Pressing the **BK**, from RUN mode, to access directly to the echoes digital map display, which are in **PTU50-51-56** receiving (Fig.26).

This function is useful for:

- properly orient the transducer pointing.
- verify the echoes in acquisition correctness.
- identify any false echo signals that may cause measurement errors.

Fig.26






Fig.27

SGM-LEKTRA S.r.l. Via Papa Giovanni XXIII, 49 - 20090 Rodano (MI) - ITALY-


tel: ++39 0295328257 fax: ++39 0295328321


web: www.sgm-lektra.com e-mail: info@sgm-lektra.com

6. ADVANCED CONFIGURATION MODE

From "RUN" mode, holding down , press **OK** to the advanced configuration mode access




press  to select the menu and press **OK** to access. Press **BK** to exit




6.1 Advanced setup menu structure


6.1.1 "SETUP" menu




6.1.2 "DISPLAY" menu




6.1.3 “DIAGNOSTIC” menu



6.1.4 “SERVICE” menu




6.1.4 “INFO” menu




(*)This function is only active for PTU51 and PTU56

7. ADVANCED CONFIGURATION DETAIL

7.1 SETUP

From “RUN” mode, holding down , press **OK** to access

►SETUP
DISPLAY
DIAGNOSTIC
SERVICE
INFO

Select the parameters by moving the cursor with  and confirm with **OK**

►SET DISTANCE 4mA 1
SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

7.1.1 SET DISTANCE 4mA

Position the ► cursor on DISTANCE 4mA, press **OK** to enter

Use **▲** and **▼** to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 1500mm (**PTU50** range 1.5m), or 6000mm (**PTU51** range 6m) or 12000mm (**PTU56** range 12m)

►SET DISTANCE 4mA 1
SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

SET DISTANCE 4mA 1.1

5000 mm

7.1.2 SET DISTANCE 20mA

Position the ► cursor on SET DISTANCE 20mA, press **OK** to enter

Use **▲** and **▼** to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 100mm (**PTU50** range 1.5m), or 400mm (**PTU51** range 6m) or 600mm (**PTU56** range 12m)

SET DISTANCE 4mA 1
►SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

SET DISTANCE 20mA 1.2

0300 mm

7.1.3 MEDIUM

Position the ► cursor on MEDIUM, press **OK** to enter

Sono possibili 3 configurazioni:

SOLIDS - granular solids measurement

LIQUIDS - liquids measurement

LIQUIDS PIPE - liquids measurement in pipe reference

Press **▼** to select the product type.

Press **OK** to confirm. **BK** to exit without changes

Default value: LIQUIDS

SET DISTANCE 4mA 1
SET DISTANCE 20mA
►MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

MEDIUM 1.3

SOLIDS

►LIQUIDS

LIQUIDS PIPE

7.1.4 FILTER COEFFICIENT

Position the ► cursor on FILTER COEFFICIENT, press **OK** to enter

Immettere un valore da 1 a 99. 1 massima velocità, 99 massima

lentezza. 0 esclude il filtro rendendo immediata la risposta

Use **▲** and **▼** to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 20

SET DISTANCE 4mA 1
SET DISTANCE 20mA
MEDIUM
►FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

FILTER COEFF. 1.4

20

7.1.5 BLIND DISTANCE

Position the ► cursor on BLIND DISTANCE, press **OK** to enter

1
SET DISTANCE 4mA
SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
► BLIND DISTANCE
ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

Represent the "BLIND ZONE" of the sensor. Input the desired value in order to avoid measures near the surface of the sensor (if necessary).

The minimum value is 50mm (PTU50), or 300mm (PTU51) or 500mm (PTU56)

Use **▲** and **▼** to modify the value.

Press **OK** to confirm.

Default values: 50mm (PTU50), or 300mm (range 5m) or 500mm (PTU56)

1.4
BLIND DISTANCE
0600 mm

7.1.6 ACTUAL LEV. 4mA

Position the ► cursor on ACTUAL LEV. 4mA, press **OK** to enter

Self distance learning function that is associated with the 4mA (lower value). Make sure that the level corresponds to 0%,

OK to associate the actual measure with 4mA output value;

OK TO CONFIRM . **BK** to exit without change

1
SET DISTANCE 4mA
SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
► ACTUAL LEV. 4mA
ACTUAL LEV. 20mA

7.1.7 ACTUAL LEV. 20mA

Place the ► cursor on ACTUAL LEV. 20mA, press **OK** to enter

Self distance learning function that is associated with the 20mA (lower value). Make sure that the level corresponds to 100%,

OK to associate the actual measure with 20mA output value;

OK TO CONFIRM . **BK** to exit without change

1
SET DISTANCE 4mA
SET DISTANCE 20mA
MEDIUM
FILTER COEFFICIENT
BLIND DISTANCE
ACTUAL LEV. 4mA
► ACTUAL LEV. 20mA

7.2 DISPLAY

From "RUN" mode, holding down **▲** , press **OK** to access

Position the ► cursor on DISPLAY, press **OK** to enter

SETUP
► DISPLAY
DIAGNOSTIC
SERVICE
INFO

Select the parameters by moving the cursor with **▲** and **▼** and confirm with **OK**

2
► DISPLAY VALUES
ECHO MAP
LCD CONTRAST
WELCOME TEXT

7.2.1 DISPLAY VALUES

Position the ► cursor on DISPLAY VALUES, press **OK** to enter

2
► DISPLAY VALUES
ECHO MAP
LCD CONTRAST
WELCOME TEXT

It's possible to select if one value with big digits or two values are shown on the display in "RUN" mode

With the **▲** button you can select the parameter to be programmed.

Press **OK** to confirm. **BK** to exit without changes


2.1
DISPLAY VALUES
► 1 VALUE
2 VALUES

7.2.1.1 1 VALUE

Position the ► cursor on 1 VALUE, press **OK** to enter

Only one value is displayed; it's possible to choose from 5 parameters.
With the **↓** button you can select data to display.

Press **OK** to confirm. **BK** to exit without changes








7.2.1.2 2 VALUES

Position the ► cursor on 2 VALUES, press **OK** to enter

Two values are displayed; it's possible to choose which one is the primary and which is the secondary, each with a choice of 5 parameters.
With the **↓** button you can select data to display



Press **OK** to confirm. **BK** to exit without changes



7.2.2 ECHO MAP

Position the ► cursor on ECHO MAP, press **OK** to enter

Detailed function description on page 13, figure 34
BK to exit and return to the menu 2



7.2.3 LCD CONTRAST


Position the ► cursor on LCD CONTRAST, press **OK** to enter

it's possible to adjust the contrast of LCD, simply increasing or decreasing the value of a parameter from 0 to 63.

Use **▲** and **▼** to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 32



7.2.4 WELCOME TEXT


Position the ► cursor on WELCOME TEXT, press **OK** to enter

It's possible to edit or delete the message that is displayed by the PTU51-56 during the ignition phase.

Use **▲** (up scroll) and **▼** (down scroll) to change the digit; **OK** to move the digit to the right. To confirm press **OK** repeatedly until leave the parameter.

BK to exit without changes

Default value: SGM-LEKTRA PTU5x




7.3 DIAGNOSTIC

From "RUN" mode, holding down **▲**, press **OK** to access

Position the ► cursor on DIAGNOSTIC, press **OK** to enter


Select the parameters by moving the cursor with **▲** and **▼** and confirm with **OK**





7.3.1 FALSE ECHO DETECT

Position the ► cursor on FALSE ECHO DETECT, press **OK** to enter

NB - To use this parameter the tank *must strictly be empty*
 This function is only active for PTU51 and PTU56



It's necessary to input the empty distance (distance from the tank bottom)
Use  and  to modify the value.

Press **OK** to confirm. **BK** to exit without changes

"PTU51-56" automatically stores all echoes detected and implemented an echo true and any eventual spurious echoes automatic selection. After this, the following message is displayed: **FALSE ECHO DETECT PROGRESS**
After procedure completion, the detected false echoes distances are displayed and automatically stored (up to 3 false echoes). Press **OK** to return to the "DIAGNOSTIC" menu If something's not correct

(e.g wrong empty distance value, obstacles that hides the bottom) the following message is displayed:
FALSE ECHO DETECT ERROR

*Note: False echo detect procedure is not recommended for pipe and stand-pipe applications
To delete this function, need to restore the default parameters (see par. 7.4.5)*

3.1
SET EMPTY DISTANCE
0000 mm

7.3.3 MEASURE STATUS

Position the  cursor on MEASURE STATUS, press **OK** to enter

It's possible to display the gain of the system, with values from 0 to 255.
While displayed, the automatic gain control is not active
BK to exit



3
FALSE ECHO DETECT
▶ MEASURE STATUS
FROZEN GAIN
MAX GAIN TH.
PEAK VALUES
OUTPUT SIMUL.

3.2
MEASURE STATUS
G : 00000

7.3.4 FROZEN GAIN

Position the  cursor on FROZEN GAIN, press **OK** to enter

It's possible to fix a value of gain (from 1 to 255) and consequently disable the automatic gain control. Once the value is 000 the automatic gain control restarts

Use  and  to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 000



3
FALSE ECHO DETECT
MEASURE STATUS
▶ FROZEN GAIN
MAX GAIN TH.
PEAK VALUES
OUTPUT SIMUL.

3.3
FROZEN GAIN
000

7.3.5 MAX GAIN TH

Position the  cursor on **MAX GAIN TH**, press **OK** to enter

It's possible to input a value of gain that it should be not reached in normal operation. If the gain exceeds this value, the "GAIN" error code is activated.

Use  and  to modify the value.

Press **OK** to confirm. **BK** to exit without changes

Default value: 255 (Max gain)

3
FALSE ECHO DETECT
MEASURE STATUS
FROZEN GAIN
▶ MAX GAIN TH.
PEAK VALUES
OUTPUT SIMUL.

3.4
MAX GAIN TH
255

7.3.6 PEAK VALUES

Position the ► cursor on PEAK VALUES, press **OK** to enter

3
FALSE ECHO DETECT
MEASURE STATUS
FROZEN GAIN
MAX GAIN TH.
►PEAK VALUES
OUTPUT SIMUL.

The system store the maximum distance and the minimum distance measured since the power is turned ON.

It's possible to see those values or reset the values

With the **◀▶** button you can select the function.

Press **OK** to confirm.

3.5
►DISPLAY VALUES
RESET VALUES

7.3.6.1 DISPLAY VALUES

Position the ► cursor on DISPLAY VALUES, press **OK** to enter

3.5
►DISPLAY VALUES
RESET VALUES

Displays the max. and min. distance measured from power on.

BK to exit.

NB - The peak values stored are erased every time the PTU51-56 turns-off

3.5.1
PEAK VALUES
MAX 0000mm
MIN 0000mm

7.3.6.2 RESET VALUES

Position the ► cursor on RESET VALUES, press **OK** to reset

BK to return to the previous menu.

3.5
DISPLAY VALUES
►RESET VALUES

7.3.7 OUTPUT SIMULATION

WARNING - entering in the SIMULATION function, the current output is not in function of the level measurement. To restore the current as a measured level function, press the **OK** button 3 times (RUN mode)

Position the ► cursor on OUTPUT SIMULATION, press **OK** to enter .

It's possible to force the analog output to a desired value.

Use **▲** and **▼** to modify the value.

Press **BK** to return to the previous menu.



3
FALSE ECHO DETECT
MEASURE STATUS
FROZEN GAIN
MAX GAIN TH.
PEAK VALUES
►OUTPUT SIMUL.

3.6
OUTPUT SIMUL.
00.0 mA

7.4 SERVICE


From "RUN" mode, holding down , press  to access

Position the  cursor on SERVICE, press  to enter

Select the parameters by moving the cursor with  and confirm with 



4
SETUP
DISPLAY
DIAGNOSTIC
▶SERVICE
INFO



4
▶OUTPUT SAFE MODE
SET UID
LANGUAGE
FREQUENCY
F. WINDOW
RESTORE SETTINGS

7.4.1 OUTPUT SAFE MODE


Position the  cursor on OUTPUT SAFE MODE, press  to enter

It's possible to choose a analog output value durin diagnostic errors.

"**21.5 mA**" forces the current output to 21,5mA


"**3.85 mA**" forces the current output to 3,85mA

"**HOLD LAST VALUE**" maintains the output at the last valid value.


With the  button you can select the operation mode.

Press  to confirm.  to exit without changes

Default value: HOLD LAST VALUE



4
▶OUTPUT SAFE MODE
SET UID
LANGUAGE
FREQUENCY
F. WINDOW
RESTORE SETTINGS





4.1
OUTPUT SAFE MODE
▶21.5 mA
3.85 mA
HOLD LAST VALUE

7.4.2 SET UID


Position the  cursor on SET UID, press  to enter

Can assign the address UID in this parameter, for a MUDBUS RTU network

Use  and  to modify the value.

Press  to confirm.  to exit without changes

Default value: 001



4
▶OUTPUT SAFE MODE
SET UID
LANGUAGE
FREQUENCY
F. WINDOW
RESTORE SETTINGS




4.2
SET UID
001

7.4.3 LANGUAGE

Position the  cursor on LANGUAGE, press  to enter

Sets the menu language: English, Italian, French

Press  to select the menu language.

Press  to confirm.  to exit without changes



4
▶OUTPUT SAFE MODE
SET UID
LANGUAGE
FREQUENCY
F. WINDOW
RESTORE SETTINGS




4.3
LANGUAGE
▶ENGLISH
ITALIANO
FRANCAIS

7.4.5 CHECK FREQUENCY

Position the ► cursor on CHECK FREQUENCY, press **OK** to enter

It's possible to check the computed sensor emission frequency
BK to exit



7.4.6 F. WINDOWS

Position the ► cursor on F. WINDOWS, press **OK** to enter

Refer to figure 34 on page 13 .The F.WINDOW is the sensitive area width around the true echo. All echoes detected inside the F.WINDOW are valid. F.WINDOW automatically centers itself in the most probable echo neighborhood and automatically adjusts its width (step). The step value of the window, expressed in cm, is represented by SET WIDTH; for example: parameter set to 5; the sensor is hooked to a 4m distant signal echo; suddenly the echo signal disappears and a echo signal is detected to 1m; PTU51-56 will start to open the search range with steps of 5cm at each echo signal emission, so to cover the 3 meters that separate the 4m distant signal echo by the new 1m distant echo, PTU51-56 will take 60 emissions to reach the new 1m distance eco. This parameter serves to filter false echo signals products, for example, by the agitator blades. Range: 00÷20

Press **OK** to confirm. **BK** to exit without changes

Default value: 05



7.4.5 RESTORE SETTING

Position the ► cursor on RESTORE SETTING, press **OK** to enter

Press **OK** to restore the PTU51-56 default settings

BK to exit whitout restored the PTU51-56 default settings.




7.5 INFO

Position the ► cursor on INFO, press **OK** to enter

In addition to information about the manufacturer, are displayed the firmware revision and the configuration index.

BK to exit.



This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

SGM-LEKTRA S.r.l. Via Papa Giovanni XXIII, 49 - 20090 Rodano (MI) - ITALY-
tel: ++39 0295328257 **fax:** ++39 0295328321
web: www.sgm-lektra.com **e-mail:** info@sgm-lektra.com